

5 PARTS LIST



Qty -011	Qty -013	Qty -021	Qty -023	Qty -031	Qty -033	Qty -041	Part Number	Description
X							D505-1049-011	BEARPAW INSTALLATION
	X						D505-1049-013	BEARPAW INSTALLATION WITH WEARPLATES
		X					D505-1049-021	BEARPAW INSTALLATION
			X				D505-1049-023	BEARPAW INSTALLATION WITH WEARPLATES
				X			D505-1049-031	BEARPAW INSTALLATION
					X		D505-1049-033	BEARPAW INSTALLATION WITH WEARPLATES
						X	D505-1049-041	WEARPLATE KIT
8	8	8	8	8	8		D2274	Radius Block
16	16	16	16	16	16	8	D2529	Washer
		4	4				D4011-1	Clamp
				4	4		D4011-3	Clamp
		4	4	4	4		D4012-1	Cushion
	2		2		2	2	D5559-041	Wearplate
2	2	2	2				D5560-1	Bearpaw
				2	2		D5560-3	Bearpaw
4	4						D5566-1	Clamp
4	4						D5567-1	Cushion
	8		8		8	8	AN4C7A	Bolt
8	16	8	16	8	16	8	MS21043-4	Nut
8	8	8	8	8	8		MS21083C4	Nut
8	8	8	8	8	8		NAS1149D0463J	Washer
8	8	8	8	8	8		NAS1802-4-32	Screw
2	2						QS200-M40S	Hose Clamp
		2	2	2	2		QS200-M44S	Hose Clamp

PRELIMINARY

Rev. PC1

• COPYRIGHT © 2017 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: C

Date: 19.03.11